

TECHNICAL INFORMATION

GymCare (Sportbodenpflege)



Water-based wipe care product. Cleaning and protecting in one step.

- For regular wipe care in sports halls
- Can also be machine applied
- Meets the requirements of German and European sports flooring standards
- Extremely economical concentrate
- No basic cleaning required

Range of use:

Suitable for cleaning and caring for PVC, linoleum and rubber coverings in sports halls.

EN 14904

Technical Data

Art.-no.

10059



10 l



60

pH

7.4

Contents

< 5% non-ionic surfactants, LIMONENE, perfumes, METHYLCHLOROISOTHIAZOLINONE, METHYLISOTHIAZOLINONE

Storage and transportation

36 months of storage stability. No hazardous material according to ADR. Store and transport between +5 to +25°C. Protect from frost.

GISCODE

GU83

02/07/2020



Application

- Remove any loose dirt and dust in advance using a vacuum, brush or mop.
- Observe the general and, if available, the product-specific health and safety instructions. More specific information relating to GISCODE can be found in the usage instructions, which are available at www.wingis-online.de.
- Shake the contents well.

Thinner

Water.

Application tool/application rate

LOBATOOL mop. On large areas, use a suitable flat wiper mop or a scourer-vacuum machine. / Depending on the application, add approx. 500 - 1000ml to a bucket with 10 l of water, sufficient for 100 m².

Drying time

- Approx. 60 min.

Application:

Initial care

If initial care with a dispersion care product such as LOBACARE[®] SportCare is not possible, mix Sportbodenpflege in a ratio of 1:10 with water and treat the flooring with it. Wipe any excessively wet areas. Do not polish.

Maintenance care (manual)

Mix Sportbodenpflege in a ratio of 1:20 with water and apply with a wiper mop. For spot cleaning, apply Sportbodenpflege undiluted onto the soiled areas and clean intensively with a cleaning machine or moistened hand pad.

Maintenance care (machine)

Mix Sportbodenpflege in a ratio of 1:10 with water and clean the flooring with a scourer-vacuum machine. To ensure an adequate care result, do not vacuum off immediately. Allow any residual moisture to dry on the surface. For spot cleaning, apply Sportbodenpflege undiluted onto the soiled areas and clean intensively with a cleaning machine or moistened hand pad.

Stripping:

The product can be removed again by stripping it with LOBACARE[®] Grundreiniger special, although for linoleum flooring LOBACARE[®] CareRemover must be used. For details, see the product's technical information.

Important information

The surface must not be flooded with cleaning solution. Using too much water and allowing the product to work for too long can cause swelling and must therefore be avoided. Moisture that has penetrated equipment jackets can cause covering swelling and corrosion, therefore the jacket cover should be left open to dry.



TECHNICAL INFORMATION

GymCare (Sportbodenpflege)



General guidelines

Cleaning of tools: Clean tools and equipment immediately with water.

Drying time: The indicated drying times are valid for +20°C and 50% relative humidity, and assume careful, draught-free ventilation of the working area. Lower temperatures, higher relative humidity or poorer ventilation lead to longer drying times. Do not apply any protective coverings, wet clean the surface or lay carpet until the coating has achieved its final hardening. Product-specific data can be found in the relevant technical information.

The information in this document and all other advice and recommendations that we provide to help and assist the applicator are based on previous experience and relate to Spezial conditions. Because of the wide range of possible uses and conditions of application of our products, we do not relieve users from the need to carry out their own trials or to seek technical advice by speaking to the LOBA application engineering department. Observe the floor covering manufacturer's recommendations and the provisions of the current standards. Our liabilities and responsibilities are exclusively in accordance with our Terms and Conditions and are not extended by this information or by our advice. The publishing of a new technical data sheet automatically invalidates the earlier version.

The words or symbols denoted by ® stand for trademark rights that are at least registered and protected in the territory of Germany.

02/07/2020

